

## MiHO014 In-line Relay fitting Instructions

- 1) Before commencing work, isolate the mains power supply and remove the fuse in the fuse box or switch off the circuit breaker in the consumer unit.
- 2) Connect the wires as shown in the wiring diagram attached. Ensure the cables are stripped to an appropriate length of between 6mm and 10mm. Ensure the cables are fully inserted into the terminals and that the terminals are properly tightened and no bare wire is visible.
- 3) Screw the unit to a suitable flat vertical surface at least 400mm above the adjacent floor.
- 4) This product must be installed in accordance with the latest Building and IET Wiring Regulations. If in any doubt, please contact a qualified electrician.

For indoor use only

