



30 Minute Rundown Timer

Reduces the risk of fires caused by heating appliances such as irons and hair straighteners being left accidentally on.

How to use

Press the button on the front of the Timer to enable the socket for 30 minutes and use your appliance. The lamp on the front will flash on and off while the Timer is counting down.

After 30 minutes the socket will be turned off and the lamp will stop flashing.

Press the button again to enable the socket on the Timer for another 30 minutes at any time.

Switch off at the mains socket or remove from the socket to remove power.



Removes mains power to the socket after 30 minutes

For irons, hair straighteners and other appliances



Most suitable for irons and hair straighteners to reduce the risk of fire when accidentally left on.

Technical Information

Approved to the appropriate parts of BS5733, EN60730
Voltage: 220-250V AC 50Hz
Max. current: 1 3A
Max. power: 3kW
Product Code: ENER001

Indoor use only

